

iDrive Knob Controller Operation Guide



Press and hold "**BACK**" button for 2 seconds to switch between original NBT and Dynavin menu.

Dynavin iDrive operation video

Please watch the video below before operating the Dynavin NBT unit.



dynavin.de/NBT-idrive

Navigation Map File

Due to the storage space limitation, not all of the map files are installed in the Ultra Flex system.

Please configure the map file in the Map Updates menu.
For the latest map file, please download it from flex.dynavin.com

System Reboot

If you have any issues during use, tap the System Reset icon from the main menu and tap the "Restart" option.

Support

Please download the latest software version from <https://flex.dynavin.com>

For further assistance, contact us at <https://support.dynavin.com/technical>


Instruction Manual

Scan the appropriate QR code or visit the website indicated below for the Dynavin User Manual and/or the Navigation App Manual.

Dynavin User Manual



German version
dynavin.de/user-manual-de



English version
dynavin.de/user-manual-en



French version
dynavin.de/user-manual-fr

Navigation App Manual



German version
dynavin.de/dynaway-manual-de



English version
dynavin.de/dynaway-manual-en



French version
dynavin.de/dynaway-manual-fr