

Instructions for the Intended Operation

Only use the device in the location intended for it. In case of improper use, improper installation or modifications, the operating permit and the warranty will become void.

The instructions listed here apply to most, but not all products equally! If you have any questions about this, please contact your dealer.



Risk of damage to the electronics. Never open the housing of the device unless instructed to do so by the manual or the service team. Otherwise the warranty will be voided.



Always have repairs carried out by our service partners only! Devices repaired by yourself will void the warranty!



Attention ! Never overload the power connections or extension cables. Fire hazard !



Attention ! Never insert foreign objects into the openings on the housing!
The objects can damage the electronics or cause short circuits.



Attention ! If cables or connectors of the item are damaged, de-energize the item and contact your dealer. Danger of fire or electric shock.



Attention ! In case of smoke, noise and/or odor development, switch off the device immediately and disconnect it from the power supply. Do not continue to use the device!
Contact your dealer!



Attention ! Do not expose the device to direct sunlight or other heat sources! Never install the device near radiators, hot air hoses or other heat sources.



Attention ! Ensure sufficient air circulation to avoid damage to the device components. components. Do not cover any opening of the device.



If you need to replace a fuse, switch off the device and disconnect the power supply. Only use fuses of the same rating as replacements.



Attention ! Do not place magnets or magnetic tools on the items.
This may cause damage to the item or loss of data.